

# FASTRAK DIGITIZER HIGH-FIDELITY 3D DIGITIZING SYSTEM

The FASTRAK<sup>®</sup> Digitizer provides unmatched accuracy in an ultra portable and easy to set-up package. FASTRAK<sup>®</sup> Digitizer is a trusted asset for EEG localization, rapid prototyping and CAD applications.



#### HOW IT WORKS

FASTRAK Digitizer allows for the digitizing of points with our digitizing stylus, using a single electromagnetic source. The source emits an electromagnetic field in which the stylus and optional sensors are tracked in full 6DOF (6 Degrees-Of-Freedom). The included hand/foot switch provides users an alternative option to the built-in button on the stylus. Press the button, capture a point--simple!

#### APPLICATIONS

EEG LOCALIZATIONREVERSE ENGINEERINGRAPID PROTOTYPINGCAD MODELING

#### FEATURES



### OPTIONS



Standard Sensor (RX2)



3-inch Digitizing Stylus (ST3)



4-inch Source (TX4)

### COMPONENTS

The standard FASTRAK® Digitizer system includes an SEU (System Electronics Unit), 8-inch stylus, 2-inch source (TX2) and the hand/foot switch. For additional motion tracking, you can easily expand the system's capabilities by adding up to three sensors or by upgrading to a larger source.

#### SYSTEM ELECTRONICS UNIT

Contains the hardware and software necessary to generate and sense the magnetic fields, compute position and orientation, and interface with the host computer via USB, RS-232 or optional RS-422.

DIMENSIONS: 10.2 in (25.9 cm) x 11.5 in (29.2 cm) x

ST8 DIGITIZING STYLUS

A lightweight stylus designed for capturing precise position and orientation data.

DIMENSIONS: 7 in (20.32 cm) x 0.5 in (1.27cm) x 0.75 in (1.91cm)

SOURCE OPTIONS

The source generates the magnetic field in which the stylus/sensor is tracked.

TX2 - WEIGHT: 8.8 oz (250 g) DIMENSIONS: 2.3 in (5.84 cm) x 2.2 in (5.08 cm) x 2.3 in (5.84 cm)

TX4 - WEIGHT: 1.60 lbs (726 g) DIMENSIONS: 4.07 in (10.33 cm) x 4.07 in (10.33 cm) x 4.04 in (10.16 cm)


TX1 - WEIGHT: 0.36 oz (10.2 g) DIMENSIONS: .9 in (2.29 cm) x 1.11 in (2.82 cm) x .6 in (1.52 cm)

## Dimensions and weight are approximate. Dimensional drawings available upon request. SPECIFICATIONS

2.3 in (5.8 cm)

UPDATE RATE	120 updates/second divided by the number of sensors	
INTERFACE	USB; RS-232 with selectable baud rates up to 115.2 K (optional RS-422)	
LATENCY	4 milliseconds	
STATIC ACCURACY (IN A MAGNETICALLY CLEAN ENVIERONMENT)	0.03 inches RMS for the X, Y, or Z position; 0.15° RMS for sensor orientation. The system will provide the specified performance when the sensors are within 30 inches of the source. Operation over a range of up to 10 feet is possible with slightly reduced performance.*	
OPERATING TEMPERATURE	10°C to 40°C at a relative humidity of 10% to 95%, noncondensing	
POWER REQUIREMENTS	15 W, 100-240 VAC, 47-63Hz	
SOFTWARE TOOLS	GUI included USB drivers for Microsoft Windows® Linux® - contact Polhemus	
REGULATORY	FCC Part 15, class A EN61326-1: 2013 Emission EN61326-1: 2013 Immunity, Basic Environment	

## RANGE VS RESOLUTION



Range (inches)	Position Resolution (inches)	Orientation Resolution (degrees)
12.0	0.00023	0.0026
24.0	0.0030	0.0147
36.0	0.019	0.0558
48.0	0.055	0.1266
72.0	0.346	0.369
120.0	1.605	2.960

## **GET IN TOUCH**

Our technology powers applications in a wide variety of markets, catering to healthcare, military, and in countless research areas. Talk with our Motion Tracking Experts™ today.

POLHEMUS.COM



40 Hercules Drive / PO Box 560 Colchester, Vermont 05446-0560 US & Canada: 800.357.4777 / 802.655.3159 Fax: 802.655.1439



\*Large metallic objects, such as desks or cabinets, located near the source or sensor, may adversely affect the performance of the system.

FASTRAK is a trademark of Polhemus Copyright © 2018 Polhemus, MS104 Microsoft Windows is a registered trademark of Microsoft Corporation. Linux is a registered trademark of Linus Torvalds.

(

Polhemus is a Good Manufacturing Practices (GMP) Contract Manufacturer under U.S. FDA Regulations. We are not a manufacturer of Medical Devices. Polhemus systems are not certified for medical or biomedical use. Any references to medical or bio-medical use are examples of what medical companies have done with the products after they have obtained all necessary or appropriate medical certifications. The end user/OEM/VAR must comply with all pertinent FDA/CE regulations pertaining to the development and sale of medical devices and all other regulatory requirements.